



HV-203 COMPRESSOR BODY

Compressor Spare Parts List

Part No	Description	Q'ty	Part No	Description	Q'ty	Part No	Description	Q'ty
1011	Cylinder head (L)	1	2531	Outlet valve plate (L)	1	4731	Flywheel	1
1012	Cylinder head (H)	1	2535	Outlet valve plate (H)	1	4732	Set bolt	1
1021	Head packing (L)	1	2541	Outlet valve spring (L)	1	4761	Flywheel washer	1
1022	Head packing (H)	1	2545	Outlet valve spring (H)	1	4781	Spring washer	1
1031	Set bolt (L)	4	2591	Valve packing (L)	1	4811	Flywheel key	1
1032	Set bolt (H)	4	2592	Valve packing (H)	1	4821	Stopping washer	1
1038	Washer (L)	4	3011	Cylinder (L)	1	4831	Snap ring	1
1039	Washer (H)	4	3012	Cylinder (H)	1	5011	Piston (L)	1
1051	Unloading nut (L)	1	3021	Cylinder packing (L)	1	5012	Piston (H)	1
1052	Unloading nut (H)	1	3022	Cylinder packing (H)	1	5021	Compression ring (I,L)	1
1060	Unloading piston (L)	1	3033	Set bolt (L)	4	5022	Compression ring (I,H)	1
1061	Unloading piston (H)	1	3034	Set bolt (H)	4	5026	Compression ring (II,L)	1
1068	Unloading piston rod (L)	1	3035	Set nut (L)	4	5027	Compression ring (II,H)	1
1069	Unloading piston (H)	1	3036	Set nut (H)	4	5031	oil scraper ring (L)	2
1072	Unloading holder (H)	1	3038	Washer (L)	4	5035	oil scraper ring (H)	1
1077	Unloading fork-seat (H)	1	3039	Washer (H)	4	5111	Piston pin (L)	1
1081	Unloading fork (L)	1	4011	Crankcase	1	5112	Piston pin (H)	1
1082	Unloading fork (H)	1	4060	Breathing cap	1	5211	Snap ring (L)	2
1087	Unloading spring (L)	1	4071	Steel ball	1	5212	Snap ring (H)	2
1088	Unloading spring (H)	1	4083	O-ring	1	5711	Connecting rod (L)	1
1089	Spring seat (I)	1	4091	Oil plug	1	5712	Connecting rod (H)	1
2000	Inlet valve set (L)	1	4092	O-ring	1	5781	Crank pin bush	2
2001	Inlet valve set (H)	1	4211	Oil gauge	1	5783	Set bolt	2
2011	Inlet valve seat (L)	1	4221	Seal ring	1	5784	Set nut	2
2012	Inlet valve seat (H)	1	4291	Level plate	1	5785	Washer	2
2031	Inlet valve plate (L)	1	4321	Bearing case	1	5792	Piston pin bush (H)	1
2035	Inlet valve plate (H)	1	4351	Bearing case packing	1	7251	Oil drain-plug	1
2041	Inlet valve spring (L)	1	4371	Set bolt	4	7253	Oil drain-washer	1
2045	Inlet valve spring (H)	1	4412	Front bearing	1	7310	Filter assy	1
2051	Valve bolt (L)	1	4421	Rear bearing seal	1	7312	Filter element	1
2052	Valve bolt (H)	1	4422	Rear bearing	1			
2511	Outlet valve seat (L)	1	4511	Front cover	1			
2512	Outlet valve seat (H)	1	4711	Crank shaft	1			

Note: Specification subject to change without notice.