



SW-307/310 COMPRESSOR BODY

Compressor Spare Parts List

Part No	Description	Q'ty	Part No	Description	Q'ty	Part No	Description	Q'ty
1011	Cylinder head	3	4011	Crankcase	1	4781	Spring washer	1
1021	Head packing	3	4060	Breathing cap	1	4811	Flywheel key	1
1031	Set bolt	12	4071	Steel ball	1	4821	Stopping washer	1
1038	Washer	12	4083	O-ring	1	4831	Snap ring	1
1051	Unloading nut	3	4091	Oil plug	1	5011	Piston	3
1060	Unloading piston	3	4092	O-ring	1	5021	Compression ring (I)	3
1068	Unloading piston rod	3	4211	Oil gauge	1	5022	Compression ring (II)	3
1081	Unloading fork	3	4221	Seal ring	1	5031	Oil scraper ring	6
1087	Unloading spring	3	4291	Level plate	1	5111	Piston pin	3
1089	Spring seat	3	4321	Bearing case	1	5211	Snap ring	6
2000	Inlet valve set	3	4351	Bearing case packing	1	5711	Connecting rod	2
2011	Inlet valve seat	3	4371	Set bolt	4	5715	Connecting rod	1
2031	Inlet valve plate	3	4412	Front bearing	1	5781	Crank pin bush	3
2041	Valve bolt	3	4421	Rear bearing seal	1	5921	Oil splash dipper	1
2051	Valve bolt	3	4422	Rear bearing	1	5931	Set bolt	3
2511	Outlet valve seat	3	4511	Front cover	1	5941	Set nut	3
2531	Outlet valve plate	3	4532	Front cover packing	1	5951	Washer	3
2541	Outlet valve spring	3	4711	Crank shaft	1	7251	Oil drain-plug	1
2591	Valve packing	3	4731	Flywheel	1	7253	Oil drain-washer	1
3011	Cylinder	3	4732	Set bolt	1	7310	Filter assy	3
3021	Cylinder packing	3	4735	Fan	1	7312	Filter element	3
3033	Set bolt	12	4736	Fan bolt	4			
3035	Set nut	12	4740	Fan washer	4			
3038	Washer	12	4761	Flywheel washer	1			

Note: Specification subject to change without notice.